


How to Measure Shipping Container Cover

Measurement Instruction

✓ Give exact measurement from edge to edge.

✓ There can be a size variance of 1" to 2"



Measurement (Inches)



1. Width

2. Flap Width

3. Flap Length

1. Width:

Width of the Shipping Container Cover



2. Flap Width:

Flap Width of the Shipping Container Cover

3. Flap Length:

Flap Length of the Shipping Container Cover

